

INSERT OF MEMORY FOAM, IT CAN BE POSITIONED IN DIFFERENT AREAS
TO ENHANCE COMFORT WHILE DRIVING

SEAT

Part number	Size
T3800	100x70 cm
T3800S	90x50 cm

LEG / BACKREST

T3801	60x50 cm
-------	----------

LUMBAR

T3802	40x20 cm
-------	----------

SIM MEMORY FOAM KIT

HOW TO USE

TOTIM® Racing



FIA — FLAME RESISTANCE TEST FOR THE FOAM MATERIALS EN ISO 15025:2003

SEAT COVERING CONFORMS TO FIA HOMOLOGATION SPECIFICATION — FLAME RESISTENCE UNI ISO 3795:1992

SIM MEMORY FOAM KIT

1 GET SET

PLACE TOTIMRACING SIM MEMORY KIT ON A RIGID FLAT SURFACE. IDENTIFY THE "SIDE UP" SYMBOL

2 POP IT

PUT YOUR HAND IN A DIAGONAL POSITION AT AN ANGLE TO POP THE MIDDLE SEAL WHILE AVOIDING ACCIDENTAL POPPING OF THE TOP SEAL

3 PRESS ON

APPLY FIRM PRESSURE DOWN WITH THE OTHER HAND IN THE DIRECTION OF THE YELLOW ARROW, GRADUALLY INCREASING PRESSURE IN THE DIRECTION OF THE GREEN ARROW, AS SHOWN IN THE IMAGE

IF NECESSARY, DO THE SAME TO THE POCKET ON THE OTHER SIDE

4 MIX FAST

ONCE BOTH POCKETS ARE POPPED, START MIXING THE TWO LIQUIDS (FOAM) AS FAST AS POSSIBLE. THE POUCH WILL START TO EXPAND UNTIL IT POPS THE TOP SEAL ON ITS OWN

MIX ACTIVATION TIME ABOUT 30/40 SECONDS

5 SPREAD IT

AFTER THE "POP" REMOVE COMPLETELY THE FOAM FROM THE INSIDE POUCH AND SPREAD IT OVER THE FULL SURFACE. PUSH A SMALL AMOUNT OF FOAM OVER THE INSIDE POUCH SO IT IS NOT FELT AFTER CURING

AFTER THE TOP SEAL "POP" AND SPREADING THE FOAM PUT THE KIT ON THE SEAT, GET IN RIGHT AWAY MAINTAINING THE CORRECT DRIVING POSITION

DURING THE FOAM EXPANSION DO NOT TOUCH THE KIT AND REMAIN STILL

▶ MIXING TIME: APPROXIMATELY 30/40 SECONDS
▶ SPREADING TIME: APPROXIMATELY 10 SECONDS
▶ MOLDING AND READY TIME: 2/3 MINUTES